



Richard Wood posted a note on the V8BB seeking help as he has just purchased the classic additions windstop, but had found the instructions consist of some very grainy photos. Could someone tell me how to connect the windstop to the brackets and which way up the side brackets go. Also the bolts that connect the actual windstop to its side brackets seem far too long.

What I really need is a clear close up of how the windstop fixes to the bracket, the part I'm most interested in is still not fully clear in the photos, I know where the other end goes (the tonneau sockets) but trying to figure out the two bolts, four washers and which little bracket is which side and which way is giving me a headache! Any detailed photos would be much appreciated.

Well we contacted Classic Additions in Shropshire and by return they sent the above photo which is enlarged alongside.

Previous RV8NOTES on the Classic Additions' windstop are:

<http://www.v8register.net/subpages/RV8NOTE224.htm>

<http://www.v8register.net/subpages/RV8NOTE228.htm>



Paul Wilson contributed RV8NOTE228 in April 2003

Paul Wilson (Woodcote Green 0929) from Yorkshire purchased a windstop for his RV8 but found he could not raise the hood with the windstop brackets in place. He set about modifying them to overcome the problem. In April 2003 he contributed RV8NOTE228. In response to the request from Richard Wood in June 2010, Paul has provided some useful photos of his windstop installation to illustrate the fixings. See pages 2 and 3 of this note.



